

Replacing the front glass

Product code 51143 contains:	1 front glass
The following tools are needed:	Flat nose pliers or similar tool
	A wrench
	Tool to mount the bauart spring, buy here .

How to replace the front glass step by step:

- Open the door.
- Dismount the [bauart](#) spring with a pair of pliers or the special tool.
- Remove the two pins which hold the door and dismount the door. If the pins are secured, remove the safety rings by using the pliers.
- Place the door face down on a soft material to protect the paint.
- Remove the clips holding the glass in place. After a period of exposure to heat it might be necessary to use some rust-dissolving oil to loosen the screws.
- Remove the glass and mount the new glass. Please note: We recommend that you change the gaskets when exchanging the glass.
- Remount the clips holding the glass in place. Avoid any direct contact between the steel parts and the glass.
- Position the door in place and mount the two pins (and the safety rings) in the hinges.
- Remount the bauart spring. However, this is only mandatory in Germany.

Hereafter you can use your stove again.